
How can I connect to my internal web server with BGs series using the public name(www.billion.com)?

For user on the local area network to connect to an internal web server using (www.billion.com). We will need to configure the Router to take care of the extreme complicated issue arises due to NAT.

The configuration steps as below.



Select"DHCP Server Mode"is "DHCP Server"



Please uncheck the box"Use Router as DNS Server",set"Primary DNS Server Address" and "Secondary DNS Server Address".Once finish enter the settings then click on the "Apply"button. To save the setting permanently.

When client PC request DNS, the Primary DNS will be the first priority.

When client PC request landomainname, DNS request will ask the Secondary DNS.